PRODUCT MANUAL



Model:A803-D

Bottle: 80ml Charging Time: 3h

Power: 2.5W N.W:195g

Introduction:

Infrared induction Indicator light

Switch -



•DC port



Directions:





Ę

- 1.Unscrew the bottle
- 2. Fill in the alcohol sanitizer, install the cotton core through the inner plug
- 3.Install the diffuser head
- 4. Press switch button about 2s to turn on machine
- 5.Get you hand cover induction area to get mist

Dimension: φ56x90mm Voltage: DC5V



0



Manual

Function indication:





- 1. You need to cover the infrared indicator area to start the mist; indicating distance 9-11 cm; every continuious mist lasts for 10 seconds.
- 2. For fast moisture, keep your hand within 5cm high from the induction area to avoid more alcohol volatilizing.
- 3. One full charging can support around 300 times use, and one-time-use based on 10 seconds mist.
- 4.Full charge power can support 24 hours standby

Indicators:

Indicator	Poweron	Power off
Battery recharging	light is on	flashing every 2s
Finish recharging	-	lightisoff

Precautions:



- 1. After installation, please keep machine vertical.Tilting or placing it flat may cause an oil overflow.The machine effciency may be affected if the circuit board is conta minated.
- 2. Shall not modify, disassemble or repair the machine arbitrarily. Any failure happens, please contact relevant technician in time.
- 3. Alcohol sanitizer only, 40%-75% Alcohol suggested, follow your country regulations for alcohol sanitizer standards.
- 4. Avoid using the machine when the sanitizer is
- Caution: Sanitizer other than Alcohol may cause harm to both the machine or human body.









PRODUCT MANUAL

A803-D











